

Hand Control Installation 2020

- 1/ Remove Blue side plates and center Flap
- 2/ cut Cable tie and slide sheath well clear of brass hose tail
- 3/ Note colour sequence of 3 colour lines
- 4/ loosen and remove 3 brass compression nuts and remove from switch . Carefully slide away from Alloy body of switch
- 5/ Rotate Brass Hose tail and Unscrew from alloy body with main air line still attached
- 6/ Remove front hose tail from Alloy Body
- 7/ After applying sealant , screw front hose tail to new switch body.
- 8/ After applying sealant , screw rear main Air Line to new switch body
- 9/ Fit the 3 new "O" rings to the coloured hoses
- 10/ in there correct position , screw each of the 3 hose compression nuts and hoses into there positions . Be very careful not to strip .
- 11/ Refit Blue covers and center flap. Dont over tighten flap bolt.
- 12/ Check for air leaks and that all parts operate freely

