


Cylinder Orifice Plates



Hole size in Brass Plate
.04 mm 1/64 th



On occasions hole in brass plate will block. When removing and replacing, make sure spring and plate are facing correct position

